



Angling Technics Limited

Technicat MkII

Thank you for purchasing this highly advanced fishing aid. Before you use it, please take a few moments to read these instructions in conjunction with the DVD. There are some aspects of the DVD have been superseded due to the change in radio frequency.



Note: When operating the boat the digital trims **MUST** always be set centrally.

Operation Instructions:

1. There is no external boat aerial as it is fitted internally.
2. The aerial on the transmitter has it optimum operating position when the aerial tip in vertical. The transmitter is supplied with, and will operate for 24 hours, using 4 off Heavy Duty AA batteries i.e. Duracell. The batteries supplied are NOT rechargeable.
When the battery level falls to an unacceptable level an alarm will sound and the LED's will flash.
3. The transmitter features digital trims. Be very careful to ensure the digital trims are not moved as this will result in the boat possibly losing some operations or not working correctly. All trims are set in the middle of their movement. If they are moved they can be reset by holding down/up the trim until the middle is found. At each end and the middle of the movement there is a long audible bleep.
4. Turn the Transmitter "ON".
5. Now turn "ON" the boat using the "ON/OFF" button. The navigation LED's will flash for 5-10 seconds while the boat registers itself to the Transmitter and then the LED's will remain "ON" or will go "OFF" depending where the left hand joystick is vertically positioned.
6. When opening the doors using the transmitter (not manually) then you **MUST** wait approximately 15-20 seconds for the door catch to return to it's natural position, if you force it's return manually, then you will stretch the door release mechanism.
7. To position your rig in the boat, pass the rig under the back of the boat and up through the open space behind the hopper compartment. Place the rig inside the hopper ensuring that the line passes through the space in the line guards. Load the rest of your free offering bait into the hopper.
8. Place the boat into the water and using the right-hand joystick steer the boat to it's destination. At the desired position release the bait and your rig by moving the left-hand joystick left or right.

9. When the hopper is released the boat LED's will go "off" (provided you are using the boat with the navigation lights "ON") until the joystick is back in the central position and the hopper has opened. The hopper can be operate independently of the other controls so you can have the option to release the bait while the boat is moving. When the bait and line has been released guide the boat back to you.
10. To get a minimum turning circle simply ensure the boat is not moving and move the right-hand joystick to the left or right (3 O'clock or 9 O'clock) leaving the joystick in the neutral position as far as the forward and reverse is concerned.
11. Moving the left-hand joystick (light control) fully back towards yourself will turn the navigation lights (LED's) to the "OFF" position. As you move the same joystick slowly forwards the navigation lights will come "ON" and gradually increase in brightness until they are fully "ON". On the last of the forward movement and when the lever is fully up the spotlight will come "ON".
When the LED's are "OFF" they will only come back "ON" at half power (dim) if the boat loses radio signal, and they will stay that way, and the boat will not move, until the radio signal is restored.
12. Remove the **Technicat MkII** from the water and gently close the hopper door. Switch "OFF" the boat by pressing the button again.
13. Switch "OFF" the transmitter.

Lights.

- Lights continuously "ON" - normal operation.
- Dim lights flashing - radio signal failure to the boat.
- Two /three second blink - hopper door(s) operated.
- No lights - transmitter set to "NO LIGHTS" mode.

Additional Operating Notes.

- a. There is no mechanical rudder used in the boat. Its steering is achieved by altering the power to the motors.
- b. The positions of the transmitter control joysticks are directly proportional to the motor power.
- c. The boat possesses a very high degree of manoeuvrability, the maximum turning force being when the throttle joystick is in the central position and the rudder joystick is at extreme right or left.
- d. With the lights (LED's) set to the "OFF" position there is no visual indication that the hopper door have opened.
- e. If it appears that the boat is becoming exhausted and may not make it back to you, then let the boat drift for a while and the batteries will recover enough energy to make the return trip. You may need to do this a couple of times. It is recommended that a bankside or solar charger be used to top up the batteries after every trip, while at the bankside.
- f. If the weed guards become blocked the steering of the boat may become impossible. Putting the boat into reverse will not clear the weed guards. If the boat appears to have a blocked weed guard, let it drift for a while as the offending blockage may fall away from the weed guard.
- g. Should the boat take in water, holding the boat with its bow facing up should drain the water from the rear drain holes. This practice is recommended at all times.
- h. The boat can be used in wind and rain. If the situation gets very difficult while the boat is still on the water, it should be driven into or away from the wind whichever is most convenient.
- i. Do **NOT** use the boat in high winds and choppy conditions.
- j. If the transmitter is turned "OFF" while the boat is still "ON" the boat lights and motors may operate erratically, this is not good practise.
- k. The motors may be operated out of water without fear of damage, unless fouled by a blockage, which interferes with the propellers. **Never** try and remove anything that is fouling the propellers with the batteries still connected.
- l. There are differences between the DVD and your boat. These changes have been made to improve the original system. These instructions supercede the DVD instructions.
- m. It is important when the boat is not being charged that the supplied cover is placed over the charging socket. This will prevent anything entering the connector and will help prevent corrosion.
- n. If you are using trout pellets or similar sized bait, ensure it does not get caught between the highest part of the door and the hull as this may prevent the door from opening fully.
- o. Always pick up the boat gently as a fully loaded boat snatched up may cause excessive strain on the handle and hull structure.
- p. Whilst reversing the boat it may not reverse in a straight line, this is due to the shape of the rear of the boat. To get the best results inch the boat backwards while moving the right hand joystick to the left or right. This will provide steering in reverse.

Batteries & Charging: There is a mains powered charger supplied with the boat. The Boat charger is capable of charging the boats batteries from fully discharged to fully charged in 18 - 20 hours. Under **NO** circumstances should the batteries for the boat be fully discharged before charging as this can severely damage them. Boat battery charging can take place at any time without any detrimental effect on their performance. If the batteries are not used for some time they will need to be regularly charged (at least every 8 weeks) to keep them in peak condition. **Please always disconnect and remove the batteries when the boat is in storage or being transported.**

Do NOT under any circumstances use batteries other than 6 volt units as this will lead to irreparable damage to your boat and will void the guarantee.

The Boat is charged while it is switched “off”.

If the boat is not going to be used for some months then every 6-8 weeks give the boat an overnight charge to ensure the batteries remain fully charged.

All rechargeable batteries will remain highly efficient if stored and maintained in a fully charged state. If the batteries are stored for long periods with very little or no charge in them, then you will probably be in a situation where the batteries will not accept a charge at all.

The Transmitter is supplied with 4 off heavy duty non-rechargeable AA batteries, which will operate the transmitter for approximately 24 hours.

CARE OF YOUR EQUIPMENT.

1. Do **NOT** drop / severally knock the **Technicat MkII** as this may damage internal parts.
2. It is recommended that the boat be wiped down with a damp cloth and allowed to dry out any condensation in a warm and dry environment for a day or two with the battery boxes left out of the boat.
3. Although the electronics are sealed, it is important that the boat and transmitter be stored in a warm, dry place, in order to prevent condensation build up.
4. The transmitter should be protected from water / condensation at all times.

Fault Diagnosis

Problem	Cause	Action
Slow running motors	Boat battery(s) voltage low	Charge the boat battery(s)
Low radio range	Boat battery(s) need recharging Transmitter batteries - low charge	Charge the boat batteries Replace transmitter batteries
Motors run correctly but there is no movement	Weed guard(s) blocked	Clean weed guard(s)
Boat does not respond to transmitter control and appears “dead”	(a) Boat battery(s) is flat (b) Transmitter batteries are flat	(a) Charge the boat battery(s) (b) Replace transmitter batteries
Door open without command / boat is out of control	Radio interference from other sources	Check other boats users or interference could be the cause
Boat goes round in circles / difficult to steer	(a) Battery(s) low on boat (b) Blocked weed guard(s)	(a) Charge battery(s) (b) Clean weed guard(s)
Door will not open	Boat battery(s) low	Charge boat battery(s)
Door will not close	There is a delay of approx 15 secs between operating the door by radio and the catches returning to their natural position.	Wait for the door catches to return naturally

Many things will cause radio interference with the boat including other boats users, CB radio, mobile phones, emergency service radios, weather (especially rain) low battery levels, radio "dead spots" (defined areas where the boat overwhelming point transmissions from unknown sources). If you suspect it is a fault with the boat then, before contacting us, please try again on another water well away the area. If you have any further questions regarding the boat, a technical helpline is available on +44 (0) 1666 575144 or fax us on +44 (0) 1666 576300.

Your boat is guaranteed for 12 months from the date of purchase. The guarantee covers any defects arising from faulty material or workmanship; it does not cover damage arising from improper use, or normal wear of the boat or associated equipment. The guarantee is invalidated if unauthorised persons undertake repairs or modifications.

To register your guarantee, please complete ALL of the following slip in BLOCK CAPITALS and return it to;

Angling Technics Limited, Unit 5, Kemble Business Park, Crudwell, Wiltshire. SN16 9SH

Tel: +44 (0) 1666 575144

Fax: +44 (0) 1666 576300

Website: www.anglingtechnics.com

If the guarantee is not completed and returned then the warranty on the Microcat will be taken from the date of manufacture.

Cut along the dotted line

Technicat MKII Guarantee

Boat Serial No:

Name:

Address:

Telephone:

Signed:

Date of Purchase:

Place of Purchase: